Screen size calculator

Enter diagonal, ratio width and height and resolution; columns F–H calculate size and PPI.

Screen	Diagonal (in)	Ratio W	Ratio H	Resolution W×H	Width (in)	Height (in)	PPI (enter px in I, J)	Pixels wide	Pixels high
Monitor A	27	16	9	2560x1440	23.53	13.24	109	2560	1440
Ultrawide	34	64	27	3440x1440	31.33	13.22	110	3440	1440